

SENTINEL MOUNTING OPTIONS COMBINATIONS

Required part ID + Functionality Description	Picture
<p>MNT001</p> <p>Base Sentinel wall mounting unit for device with RFID reader or no reader at all</p>	
<p>MNT001 + MNT005</p> <p>Base Sentinel wall mounting unit for device with magnetic stripe reader</p>	
<p>MNT001 + MNT003</p> <p>Combination of stands to mount sentinel controller with RFID reader or no reader at all on the side of a copier machine</p>	
<p>MNT001 + MNT004</p> <p>Combination of stands to mount sentinel controller with RFID reader or no reader at all on a desk</p>	
<p>MNT001 + MNT003 + MNT005</p> <p>Combination of stands to mount sentinel controller with magnetic stripe reader on the side of a copier machine</p>	
<p>MNT001 + MNT004 + MNT005</p> <p>Combination of stands to mount sentinel controller with magnetic stripe reader on a desk</p>	